

How To Use and Enjoy Your Coleman Propane Lantern Model 5114B700


U.S. PATENT U.S. PATENT
NO. D229218 NO. 3,941,55



2 To Set Up



1. Move lantern away from flame (including pilot lights) and other sources of ignition.
2. After packing is removed, close fuel valve by turning in direction of arrow.
3. Remove protective cap from top of propane bottle. Save cap for use in storing.
4. Screw propane bottle into lantern fitting by turning to right. Take care not to cross thread. Tighten firmly by hand only.
5. Place bottle securely in lantern base.



3

To Tie On Mantles

1. ALWAYS USE GENUINE COLEMAN MANTLES.
2. Tie mantle around groove in burner cap. Distribute folds of mantle evenly. Cut off surplus string.
3. Light bottom of mantle evenly. Burn until nothing but white ash remains.
4. Place globe on lantern body.
5. Assemble bail to ventilator. Place ventilator and bail on top of lantern. Finger tighten ball nut.
6. Carry spare mantles. (Type 21A)



4

To Light

1. Push lighted match through lighting hole; hold near mantle and open fuel valve fully. **Note:** If match goes out before mantle lights, close fuel valve. Repeat above procedure.
2. Brightness may be adjusted with fuel valve.



5 To Turn Off

1. Close fuel valve in direction of arrow.



6 To Store


1. Move lantern away from flame (including pilot lights) and other sources of ignition.
2. Remove propane bottle from lantern.
3. Replace protective cap on propane bottle.
4. Store in safe, clean place. (See Warning #3.)

7 Things You Should Know

1. It is unsafe and illegal in some places to store or use L.P. bottles of greater than 2½ lb. water capacity (approximately 1 lb. propane) in occupied enclosures.
2. The usual storage areas for camping and picnic equipment is the basement, attic, or garage. To avoid the accumulation of dust, cobwebs, etc. that is common in these storage areas, place your lantern in a plastic bag and seal it with a rubber band.
3. For repair service, call 1-800-835-3287 TOLL FREE for location of your nearest Coleman service center. If lantern must be mailed to service center, attach your name, address, and a description of problem to product and mail to service center prepaid. If necessary to write the service center or the factory, refer to your lantern as a model 5114B700.



Parts List for Coleman Propane Lantern model 5114B700



PART NUMBER	DESCRIPTION
21A1001	Mantle (2)
220-5231	Burner Cap and Screen (2)
220B175	Screw, S-T
275-120	Nut, Ventilator
605-210	Jamb Nut
5114-4231	Ball
5114-5251	Regulator Valve Assy.
5114-5261	Mixing Chamber
5114A0481	Globe
5114A1051	Generator Extension
5114A5991	Burner Assy.
5114B1031	Lantern Base
5114B3241	Burner Tube (2)
5114B5311	Frame Bottom and Collar Assy.
5114B5891	Generator
5114D5851	Ventilator
5410-245	Nut
5410-5291	Valve Wheel Assy.
5418-210	Disc