

## DIRECTIONS FOR USE OF FOLDING HIGH STAND

# NO. 10

- 1** Open stand (see Fig. 1) Pull frame open as far as needed so legs stand in a square.
- 2** Swing two long bars (A) attached to front legs up over and drop into slot in top end of rear legs.
- 3** Swing lid support bars (B), which are attached to rear legs, up into hook of top cross bar.
- 4** Set Camp Stove on stand so bottom rests on cross bars (A) with lid on support bar (B). Then pull front and back legs together until they touch stove. Lid will then be level and stove will not slip. **Note:** You may need to move the bottom holding support bars (B) into higher or lower holes so stove lid sits level.

This stand can be adjusted to fit all models of Camp Stoves and will as easily hold Coleman Snow-Lite Coolers, table tops, etc., by making minor height adjustments in the support bars.




FIGURE 1




FIGURE 2



**NEW**  
LIGHTWEIGHT



**FOLDING HIGH STAND**  
ALL-ALUMINUM CONSTRUCTION • EASY TO CARRY AND SET UP

**THE FOLDING STAND WITH  
DOZENS OF HANDY USES**

Wherever you go, take your handy, folding high stand. Occupies little space, yet unfolds to support heavy loads. Useful at home, too, in basement, family room, recreation room.



F7972

Lanterns, coolers, picnic jugs, camp stoves  
**THE COLEMAN COMPANY, INC.**  
Wichita 1, Kansas

**TABLE-TOP SUPPORT**  
Any board becomes a table when placed on adjustable high stand.



**SNOW-LITE COOLER SUPPORT**  
Just set cooler on support arms to save bending, stooping.



Litho. in U. S. A.