


NO. 152A GASOLINE INSTANT-LIGHTING LAMP



<u>NO.</u>	<u>NOMENCLATURE</u>	<u>NO.</u>	<u>NOMENCLATURE</u>
*21A	Mantle	129-353	Stem (Tip Cleaner)
*152SD	Shade	129-361	Finale Ass'y.
*355	Globe (Pyrex)	132-147	Nut (Handle)
**T44G	Generator (Marked "V")	132-148	Tube Ass'y. (Fuel & Air)
101-324	Tube (Burner)	132A354	Body (Valve)
104-3261	Chamber (Mixing)	150-344	Nut (Support Rod)
*104-469	Rod (Hanger)	152A165	Fount Ass'y.
112-323	Cap & Screens (Burner)	152A3991	Burner Ass'y.
118A3041	Block (Eccentric)	152A653	Stem (Valve)
118B1361	Gasket (Filler Plug)	152A657	Valve Ass'y.
118B2181	Tip (Marked "V")	200A5201	Plunger Ass'y. (Pump)
118B322	Tube (Air Intake)	216-509	Leather (Pump)
118B620	Packing (Valve Stem)	220B1401	Plug (Filler)
129-335	Clamps (Shade Holder)	242B532	Stem (Pump Air)
129-341	Finale	242B5381	Valve (Check)
129-342	Nut (Finale)	605-210	Nut (Jamb)
129-343	Rod (Shade Support)		