




PART NO.	DESCRIPTION	USED ON	PART NO.	DESCRIPTION	USED ON
8B147	Lacquer, Red		201-4851	Vent, Green	700
21A1001	021A Mantle		202-3531	Tip Cleaner Stem	
118B1361	Filler Cap Gasket (for Cap with Disc)		288-4411	Ventilator Ball Nut	
200-1481	Tube Assembly (Fuel and Air)		216-5091	Pump Cup	
200-3241	Burner Tube		220A172	Direction Disc	
200-3701	Frame and Burner Complete		220C175	Self-Tapping Screw (#4 — 40 × 5/16")	
200-4231	Ball		220C1401	Filler Cap Complete	
200-4561	Lock Nut (1/2" — 32 Hex, Brass)		242-1071	Push On Nut	
200-6381	Check Valve and Stem		242-2181	Gas Tip, Marked "6"	
200-6491	Valve Wheel		242-2381	Needle Assembly for Generator	
200-6531	Valve Stem Assembly		242-3041	Eccentric Block	
200-6571	Fuel Valve Complete (Less Generator)		242-3231	Burner Cap and Screen	
200A1651	Fount Complete	195	242-6201	Valve Stem Packing	
200A3261	"U" Tube and Venturi		242D5201	Pump Plunger Assembly	
200A6621	Burner Frame Assembly		426-426	Palnut (1/4" — 20)	
200B4841	Ventilator	195	530A5071	Pump Cap Clip	
200B4891	Globe Base Rest		605-210	Jamb Nut	
200A5891	T66DL Generator		690-066	550A Amber Pyrex Globe — Accessory	
200B1651	Fount, Green	700	690A051	550 Clear Pyrex Globe	