





Model/Modèle/Modelo 290B, 288A & 286A


Parts List

No.	290B700T	288A700T	286A700T	Description
1	#21	#21	#21	Mantle
2	290B5341	288B5341	286B5341	Burner Assembly
3	290-5891	288-5891	288-5891	Generator
4	690A048	214A0461	214A0461	Globe
5	220-4411	220-4411	220-4411	Ball Nut
6	220C1401	220C1401	220C1401	Fuel Cap
7	220A6201	220A6201	220A6201	Pump Repair Kit
8	290A6571	288A6571	286A6571	Valve Assembly (Includes Item #10)
9	290-5001	288-5001	288-5001	Ventilator & Bail
10	288C1501	288C1501	288C1501	Knob/Screw Package
11	290A5401	288A5401	286-5401	Heat Shield & Frame Bottom
12	290-6151	288-6151	286-6151	Fount Assembly
13	639-1091	639-1091	639-1091	Pump Cup & Nut
14	290B5291	288B5291	288B5291	Collar
15	288-1641	288-1641	288-1641	Nut
16	288-1251	288-1251	288-1251	U-Clip



Nomenclature

N°	290B700T	288A700T	286A700T	Désignation
1	#21	#21	#21	Manchon
2	290B5341	288B5341	286B5341	Ensemble du brûleur
3	290-5891	288-5891	288-5891	Générateur
4	690A048	214A0461	214A0461	Globe
5	220-4411	220-4411	220-4411	Écrou sphérique
6	220C1401	220C1401	220C1401	Bouchon du réservoir
7	220A6201	220A6201	220A6201	Ens. de réparation de la pompe
8	290A6571	288A6571	286A6571	Ens. de la soupape (comprend art. #10)
9	290-5001	288-5001	288-5001	Ventilateur et anse
10	288C1501	288C1501	288C1501	Paquet boutont et vis
11	290A5401	288A5401	286-5401	Pare-chaleur et fond du bâti
12	290-6151	288-6151	286-6151	Ensemble du réservoir
13	639-1091	639-1091	639-1091	Godet de la pompe et écrou
14	290B5291	288B5291	288B5291	Collier
15	288-1641	288-1641	288-1641	Écrou
16	288-1251	288-1251	288-1251	Pince en «U»



Lista de piezas

No.	290B700T	288A700T	286A700T	Descripción
1	#21	#21	#21	Mantilla
2	290B5341	288B5341	286B5341	Conjunto de quemador
3	290-5891	288-5891	288-5891	Generador
4	690A048	214A0461	214A0461	Globo
5	220-4411	220-4411	220-4411	Tuerca
6	220C1401	220C1401	220C1401	Tapa de combustible
7	220A6201	220A6201	220A6201	Juego de reparación de la bomba
8	290A6571	288A6571	286A6571	Conjunto de válvula (incluye artículo #10)
9	290-5001	288-5001	288-5001	Ventilador y manija de transporte
10	288C1501	288C1501	288C1501	Paquete de perilla y tornillos
11	290A5401	288A5401	286-5401	Protector contra el calor y base del armazón
12	290-6151	288-6151	286-6151	Conjunto de fuente
13	639-1091	639-1091	639-1091	Taza de bomba y tuerca
14	290B5291	288B5291	288B5291	Collarín
15	288-1641	288-1641	288-1641	Tuerca
16	288-1251	288-1251	288-1251	Presilla en U